



U20 (F21023) and U100 (F21024)

Description	U20	U100
A Push-button	F2070352	F2070452
B Spring-guide	F2070103	F2070103
C Connecting nut	F2072111	F2072111
D O-ring (x 5)	F161903	F2070401
E1 Piston assembly	F2070360	F2070460
E2 Return spring	F2070113	F2070113
F1 Tip holder (upper)	F2070117	F2070417
F2 Tip holder (lower)	F2070318	F2070418
G Tip ejector	F2070359	F2070459
H1 Battery Holder	F2070158	F2070158
H2 Battery	F20710	F20710
K Recalibration Tool	F20751	F20751
L Lubricant	F2070902	F2070902
M Cover	F2072107	F2072107

**Чтоб меткость и сноровку
Иметь в бою,
Храни, боец, винтовку,
Как жизнь свою.**